



Wastewater Monitoring for the Pharmaceutical Manufacturing Industry

The U.S. Environmental Protection Agency issued a final regulation in 1998 (63 FR 50388) that established standards for wastewater discharges for new and existing Pharmaceutical Manufacturing Industry (PMI) facilities. These regulations, the Pharmaceutical Effluent Guidelines found in 40 CFR Part 439, include nontraditional analytes and analytical methods specific to the pharmaceutical industry. These contaminants and appropriate methods are listed in the attached table.

EPA has developed four different subcategories in the regulations based on the type of operations performed at the facility:

Subcategory A—Fermentation Operations

Subcategory B—Biological and Natural Extraction Operations

Subcategory C—Chemical Synthesis Operations

Subcategory D—Mixing, Compounding or Formulating Operations

The specific subcategory then determines the contaminants required for monitoring.

Lancaster Laboratories has validated two of the specific methods required for determination of nontraditional analytes as part of the Pharmaceutical Effluent Guidelines (see below). Coupled with other wastewater and drinking water methods (EPA Method 524.2 for example), these can provide monitoring for all the contaminants listed in the regulation. Lancaster Laboratories has certification for these analyses through the NELAP program in Pennsylvania.



Methods for nontraditional contaminants:

- Method 1666 Revision A—Volatile Organic Compounds Specific to the Pharmaceutical Manufacturing Industry by Isotope Dilution GC/MS (for the purge-and-trap analysis).
- Method 1671 Revision A—Volatile Organic Compounds Specific to the Pharmaceutical Manufacturing Industry by GC/FID.

A baseline monitoring program as well as routine monitoring for a PMI wastewater is required under these regulations for many facilities. Lancaster Laboratories has the equipment and experience to provide the analytical services needed for this program.



Contaminants* and Methods for the Analysis of Wastewater in the Pharmaceutical Manufacturing Industry

Pollutant	CAS #	EPA Analytical Method
acetone (2-propanone)	67-64-1	524.2
acetonitrile	75-05-8	1671
<i>n</i> -amyl acetate	628-63-7	1666
<i>n</i> -amyl alcohol	71-41-0	1666
benzene	71-43-2	524.2
<i>n</i> -butyl acetate	123-86-4	1666
<i>tert</i> -butyl alcohol	75-65-0	1666
chlorobenzene	108-90-7	524.2
chloroform	67-66-3	524.2
1,2-dichlorobenzene	95-50-1	524.2
1,2-dichloroethane	107-06-2	524.2
diethylamine	109-89-7	1671
dimethyl sulfoxide (DMSO)	67-68-5	1671
ethanol	64-17-5	1671
ethyl acetate	141-78-6	1666
heptane	142-82-5	1666
hexane	110-54-3	1666
isobutyraldehyde	78-84-2	1666
isopropyl acetate	108-21-4	1666
isopropyl ether	108-20-3	1666
methanol	67-56-1	1671
methyl cellosolve	109-86-4	1671
methylene chloride	75-09-2	524.2
methyl formate	107-31-3	1666
4-methyl-2-pentanone (MIBK)	108-10-1	1666
2-propanol	67-63-0	1666
<i>n</i> -propanol	71-23-8	1671
tetrahydrofuran (THF)	109-99-9	1666
toluene	108-88-3	524.2
triethylamine	121-44-8	1671
xylene (total)		1666

*Other traditional analyses (e.g., cyanide and ammonia, may also be required.

www.LancasterLabsEnv.com

Standard Services:

Volatiles	Drinking Water
Semivolatiles	Vapor & Air Analysis
Metals	Sediment & Tissue Testing
Pesticides/PCBs/Herbicides	Method Development
Petroleum-Related Analysis	Shale Oil & Gas Analysis
Waste Characterization	
Water Quality	

Specialty Services:

Dioxins/Furans	Aldehydes
Hydrazines/NDMA	1,4-Dioxane (low level)
Explosives	Low-Level Mercury
Perchlorate	PMI
Alkyl PAHs, Alkanes, Biomarkers	Method 25D
PFC (PFOA)	Gulf Coast Services
Organic Acids	

Lancaster Laboratories, Inc.

2425 New Holland Pike
Lancaster, PA 17601
717-656-2300

For more information,
please contact
Don Wyand at Ext. 1525